## Care and Maintenance



Wash the surface with warm water and soap to remove debris and dust.



Use cleaning tissues or a microfiber cloth to wipe it lightly.



For a deeper cleaning, use a Sanitiser Antiseptic Alcohol based solution to remove dust and possible viruses.



If your divider's surface is used to write, display notes and ideas, clean it at least twice a week. Use our cleaning spray or tissues.



## REMARK

Never use abrasive solutions to clean the product and make sure that whatever material you choose is free of dirt and debris to avoid scratching the surface.

