Care and Maintenance



Wash the surface with warm water and soap to remove debris and dust.



Use cleaning tissues or a microfiber cloth to wipe it lightly.



For a deeper cleaning, use a Sanitiser Antiseptic Alcohol based solution to remove dust and possible viruses.



If your divider's surface is used to write, display notes and ideas, clean it at least twice a week. Use our cleaning spray or tissues.



REMARK

Never use abrasive solutions to clean the product and make sure that whatever material you choose is free of dirt and debris to avoid scratching the surface.

